

Blood drawing

Peripheral venous blood of adults is most often collected using *closed collection systems*. The person collecting blood is protected from contamination with the patient's blood and at the same time external contamination of the collected biological material is prevented. Mainly **vacuum collection tubes** are used. The disposable collection tube already contains preparation agents (e.g. anticoagulants or, conversely, coagulation accelerators). It is hermetically sealed and a vacuum is created in it, which ensures that the right amount of blood is sucked in during sampling. This also ensures the correct ratio of blood and preparation reagents.

Collection tubes and material prepared from venous blood

The color marking of the sampling tubes may vary according to the manufacturer and the standard. Those listed here correspond to ISO 6710 "US code" (e.g. Venosafe®, Vacuette®, Vacutainer® systems. The BS 4851 "EU code" standard (e.g. SARSTEDT® system) is also often used in the Czech Republic, where e.g. the Hematology (EDTA) tube is red. ^[1]

Serum



Blood serum is the basic material for most **routine clinical-biochemical determinations**. It is prepared from collected whole venous blood by its **precipitation** and **centrifugation**. This will **get rid of blood elements, fibrinogen and most other coagulation factors** from the material.

Precipitation of fibrin reduces the total protein concentration in serum by about 4 g/l compared to plasma. The concentration of calcium, which is consumed during coagulation, also decreases slightly.



The advantage of serum is the **good stability** of most analytes (usually hours to days when stored in the cold), it is often even possible to freeze the sample and store it for a long time. The disadvantage is the **longer preparation** of the material, coagulation and centrifugation takes around 45 minutes.

Blood for obtaining serum can be collected in a test tube without any reagents, coagulation occurs after contact with glass. Precipitation, however, takes quite a long time, for reliable results you need to wait at least 60 minutes before centrifugation. This increases the risk of hemolysis and release of intracellular components from blood elements. At the same time, metabolism in blood cells can continue for some time, which also affects the concentration of some substances. That is why tubes are mainly used, in which **coagulation activators** have been added – e.g. different forms of silicon dioxide. The addition of the activator reduces the time required for reliable coagulum precipitation to **30 minutes**.

For easier separation of the serum, there may be a **separation gel** in the collection tube. During centrifugation, blood elements and coagulum sediment under the gel, the serum remains above it. The gel facilitates the separation of the serum and at the same time it prevents contamination of the serum with the intracellular content of blood elements, which is gradually released. The separation gel is usually made of acrylate polymers with the addition of silicon dioxide, which further accelerates coagulation.

Collection tubes for the preparation of blood serum usually have a **golden yellow** (with separation gel) or a **red** (without gel) stopper.

Plasma and heparinized whole blood

The basic material for **most statistical biochemical tests** is **blood plasma**. Lithium heparin is used as an anticoagulant for its preparation. The preparation of plasma is **faster** than the preparation of serum, because the time required for blood clotting is eliminated. The tubes have walls coated with dried heparin. After collection, the blood is mixed with it by repeatedly turning the test tube, and centrifugation can be started immediately afterwards. Tubes for plasma preparation may also contain a gel to facilitate the separation of plasma from blood elements.

The addition of heparin has relatively little effect on common biochemical determinations. The lithium salt of heparin is most often used because, unlike sodium or potassium heparin, it does not change the concentration of sodium or potassium, i.e. basic and commonly determined ions.

As an anticoagulant, heparin can also be used for some examinations of "whole blood", e.g. examination of acid-base balance and blood gases. In that case, heparinized capillaries or special sampling sets with a syringe for anaerobic sampling are used. However, heparinized blood is not suitable for hematological examinations (heparin interferes with the staining of blood smears) or for molecular biological methods (it inhibits the polymerases used in PCR).

Vacuum tubes with heparin are usually marked green – tubes with separation gel have a **light green** stopper, and tubes without the separation gel have a **dark green** stopper.

Whole blood with EDTA



Vacuum tubes for serum collection. The tube with the gold cap contains the separation gel.



For examination of blood elements (**blood count**) non-coagulable whole blood is used. One of the salts of ethylenediamine tetraacetic acid (EDTA) serves as an anticoagulant in this case. The most commonly used are well-soluble potassium salts, K_2 -EDTA and K_3 -EDTA. Whole blood with EDTA is also suitable for the examination of most analytes that are intracellular in blood cells, e.g. "glycated hemoglobin" and for "DNA analysis and molecular-biological methods".



Blood with the addition of EDTA is not suitable for many other biochemical methods. The concentration of ions changes significantly and a number of enzymes are inhibited. EDTA also cannot be used to test blood coagulation, although the mechanism of its anticoagulant effect is based on the chelation of calcium ions, similar to the effect of citrate. However, the effect of EDTA cannot be completely canceled by plasma recalcification, probably because EDTA also absorbs other metals (e.g. copper) that are necessary for the function of some coagulation factors (e.g. f. V and VIII).



Test tubes with the addition of EDTA salts are most often marked with a **violet** (lavender) stopper.

Citrated plasma and citrated whole blood



Examination of **coagulation parameters** is performed from plasma decalcified with citrate. Buffered solutions of sodium citrate are mainly used. Whole blood with citrate, possibly with other additives (theophylline, adenosine and dipyridamole) is used to determine **platelet functions**. Citrate is also used as an anticoagulant in measuring the rate of **erythrocyte sedimentation**.

Citrate changes the ion concentration and inhibits some enzymes. Therefore, citrate plasma is not suitable for most biochemical determinations.

Tubes with the addition of citrate are marked with a **light blue stopper**, special tubes for erythrocyte sedimentation have a **black** stopper.

Plasma, serum and whole blood with glycolysis inhibitor



Even after blood collection, blood cells consume glucose. The glucose concentration thus gradually decreases during sample processing, depending on the temperature and other factors, by about 0.5 mmol/l per hour. Therefore, for a more reliable blood glucose determination, sampling tubes with the addition of sodium fluoride, which inhibits glycolysis, are used. There are variants both with an anticoagulant (Na_2 EDTA or potassium oxalate) for obtaining plasma, and without anticoagulant for serum preparation.

Fluoride collection tubes have a **grey stopper**.

Other and special collection tubes

A number of other variants of sampling tubes are commercially available for various other purposes – e.g. for taking samples for microbiological cultures, for toxicological analyses, determination of trace elements, with peptidase inhibitors, etc.

Other equipment necessary for venous blood collection

The quality of the material is also affected by other aids and medical devices used for sampling. Their correct choice is therefore an important part of the pre-analytical phase of the examination.

Disinfectant

For skin disinfection, alcohol disinfectants are recommended, most often **70% 2-propanol**. In addition to the requirements for antimicrobial efficiency, it is desirable from the point of view of the pre-analytical phase that the disinfectant evaporates quickly. Contamination of the collected blood with alcohol leads to hemolysis and thus to the deterioration of the sample for a number of determinations.

Iodine preparations are less suitable for blood sampling, because if they even minimally contaminate the sample, they can affect a number of determinations.

Injection needles



Vacuum tubes for collecting blood plasma. The tube with the light green cap contains the separation gel.

With closed vacuum sampling systems, special double-sided needles are most often used. When assembling the system, the cover (usually white or gray) on the side facing the tube is removed from the needle. This end of the needle is also protected by a rubber sleeve to avoid injury during handling. The needle is screwed into the holder. Just before sampling, the second cover is removed (the color corresponds to the diameter of the needle). This coloured cover protects the tip, with which the vein will be punctured. Finally, after inserting the needle into the vein, the sampling tube is inserted into the holder, while its cap is pierced with the tip, still covered by the rubber sleeve.

The blood collection needle must have a suitable **diameter**. Using too thin a needle with a vacuum system will cause large pressure differences, which can lead to hemolysis. At the same time, the collection period will be extended. If sampling is slow, initially there is a high concentration of reagents in the tube, which again can lead to hemolysis. On the other hand, a needle that is too thick will cause a larger wound, the collection may be more painful, and smaller veins may be damaged.

The diameter of injection needles is traditionally expressed in the so-called *Birmingham gauge*, and is marked with the letter G. A higher number means a thinner needle. 23 G to 18 G needles are used for blood sampling.

Blood collection needles

Color	Birmingham gauge	Outer diameter (mm)	Use
	23 G	0.64	In pediatrics
	22 G	0.72	
	21 G	0.82	Most often in adults
	20 G	0.91	
	18 G	1.27	Long collection - donating blood

Sometimes it is more convenient to use a **winged needle** (*butterfly*) instead of a needle firmly attached to the holder. It is connected to the test tube holder by a flexible tube. It has flexible plastic "wings" on it to hold it while inserting it into a vein. A winged needle is a suitable alternative for more difficult situations. It is also more convenient when drawing large numbers of tubes and is safer when drawing blood from restless and uncooperative patients.

Some needles are equipped with a safety system that covers the tip after collection to minimize the risk of injury.

Tourniquet

In general, a tourniquet should be applied at the limb from which blood is taken for as short a time as possible, otherwise a number of measured values may change. If the tourniquet is applied for a long time, the risk of hemolysis of the sample also increases. Collection should take place within one minute after the tourniquet has been applied. The tourniquet must therefore be easy to put on and release again.

Disposable tourniquets are currently preferred to reduce the risk of patient-to-patient transmission. It is necessary to monitor what material the tourniquet is made of, especially due to allergies to latex.

Venous blood sampling procedure


1. Prepare the **tools**:

sampling tubes, needle and holder, tube stand, tourniquet, disinfectant, tampons or tissue wipes, patch bandage, containers for infectious and sharp waste, non-sterile gloves, blood test request forms, stationery, sampling tubes with affixed identification labels, bags for transporting biological material.

2. Perform **hygienic hand disinfection**.



Double-sided sampling needle



Preparing the needle for collection. The white cover is removed from the double-sided needle and the needle is screwed into the holder. The colored cover is only removed just before the injection.



Collection needle ready for insertion into a vein.



Vacuum sampling system with double-sided needle.



Needle with wings ("butterfly")

3. **Prepare** and **identify** the patient.

Introduce yourself and **explain** what you will be doing. Make sure the patient **consents** to the collection.

A significant part of pre-analytical errors is caused by swapping samples. To avoid it, always just before blood drawing:

- ask the patient to say their **full name** and/or check their name on the ID bracelet,
- check some **additional data** - e.g. hospital bed number, date of birth, name of referring doctor, residential address,
- similarly check **request forms**,
- check the identification **labels** on the tubes.

Find out if the patient is **allergic** to anything (especially disinfectants, latex, patch).

Find out if the patient has had an **adverse reaction** to a blood draw (e.g. syncope) in the past. Assess unusual anxiety.

Ensure the patient is in a safe and comfortable sitting or supine **position** for sampling. The limb from which you will draw blood must be easily accessible to you and you must have all the tools within easy reach.

Place a tissue pad under the limb from which you will draw blood.

4. **Find a location** from which to collect. The vein should be visible and palpable even before the tourniquet is applied. It is not advisable to puncture the veins at the point of their branching, as this increases the risk of hematoma.
5. Select the appropriate **needle size**. Place the needle in the holder.
6. **Disinfect** the site of puncture.

Disinfection is carried out from the center to the sides. Depending on the disinfectant used, it should take around 30 seconds, after which the disinfectant should dry completely (another 30 seconds or so). After disinfection, do not touch the site of puncture, otherwise the disinfection must be repeated.

7. Perform **hygienic hand disinfection** and **put on gloves**.
8. Place the **tourniquet** about 8–10 cm above the chosen place.
9. **Insert the needle into the vein**.

Fix the vein with your thumb below the injection site.

Ask the patient to **clench fist**.

Insert the needle with a quick movement at an angle of about 30°.

10. **Fill the tubes**

Insert the test tube into the holder and pierce its stopper with a needle. The tube begins to fill with blood.

Now ask the patient to relax the fist. **Release the tourniquet**.

Fill all the prepared tubes one by one. According to WHO recommendations, the tubes are taken in the order **coagulation** (citrate, light blue) – **serum** (coagulation activator, golden yellow) – **plasma** (heparin, green) – **blood count** (EDTA, purple) – **glucose** (fluoride, gray).

Let each test tube be filled to the prescribed **volume** (blood will stop flowing). The tubes usually have the blood level marked on the label.

Once the filled tube is removed from the holder, gently **mix** it by turning it upside down and back. Tubes for the preparation of **serum** (golden yellow, red) should be **turned 5x** back and forth, **others 8x**.

11. After filling the tubes, place dry tissue wipe or a tampon on the needle and **pull the needle** off the vein. Dispose the needle in a sharps container. Compress the injection site.
12. Ask the patient to continue compressing the injection site. The limb should not be bent at the elbow, this increases the risk of a hematoma. Monitor the patient's condition after collection. Apply a patch after the bleeding has stopped.
13. Again **check** the labels on the tubes and request forms. Place the test tubes and request forms in the **transport bag**.
14. **Decontaminate** surfaces, remove gloves and perform **hygienic hand disinfection**.

Order of sampling tubes

When inserting a vacuumed sampling tube into the holder and piercing its stopper, the sampling needle may be contaminated by traces of the reagent on the inside of the stopper. Even this trace contamination can affect the results of some determinations. The tubes are therefore taken in an order that minimizes the occurrence of errors.

The tubes **without additives** are filled first, if they are used, or samples that require special collection purity (e.g. dark blue tubes for the determination of trace elements). **Citrate plasma** (light blue plug) for determination of coagulation parameters and **citrate blood** (black plug) for erythrocyte sedimentation follow. Even minimal contamination with a coagulation activator or, conversely, anticoagulant agents has a non-negligible effect on the determination of coagulation parameters and sedimentation.

Other tubes follow in the order of **serum** with coagulation activators (golden yellow or red), **plasma** with lithium heparin (green), **whole blood** for blood count with EDTA (violet) and other additives (e.g. gray tubes with fluoride for glucose determination).

A simplified typical tube collection sequence

Coagulation parameters	Serum	Plasma (statim)	Blood count	Glucose
Citrate	Clotting activators	Lithium heparin	EDTA (potassium salts)	Fluoride

Hemolysis of blood sample

A relatively common problem is hemolysis of blood during its pre-analytical processing. During hemolysis, intracellular components are released from blood cells and a number of results are distorted. It is impossible to determine, for example, serum concentrations of potassium, bilirubin, AST or lactate dehydrogenase activity, and many other determinations are imprecise.

Hemolysis can also occur intravascularly as a result of some pathological conditions. More often, however, it occurs during or after blood collection and is the result of incorrect collection technique. Causes may include:

Contamination of the sample by disinfection during collection.

Use alcohol disinfectant, let the disinfectant dry.

Applying the tourniquet too long, exercising the limb before sampling.

The tourniquet should be tightened for no longer than one minute.

Large pressure differences during sampling.

Use a stronger needle.

Blood collection from hematoma.

Avoid excessive trauma and vessel damage during collection.

Shaking the sample after collection.

Mixing the sample is done by slowly rotating the tube. Mechanical damage can also occur during transport by pipe mail.

Insufficient mixing of the sample with the reagents in the tube.

The tube must be mixed immediately after collection. Follow the recommended number of turns of the tube.

Rapid temperature changes.

Avoid rapid cooling of the sample after collection or freezing during transport.

Links

External Resources

- BD Specimen Collection Resource Library (<https://www.bd.com/en-ca/offerings/capabilities/specimen-collection/specimen-collection-resource-library?productline=3560>)

Used Literature

- DHINGRA, Neelam. *WHO Guidelines on Drawing Blood : Best Practices in Phlebotomy*. 1. edition. WHO, 2010. 109 pp. ISBN 9789241599221.
- ZIMA, Tomáš. *Laboratorní diagnostika*. 3. edition. Galén, 2013. 1146 pp. ISBN 9788074920622.
- RACEK, Jaroslav. *Klinická biochemie*. 2. edition. Galén, 2006. 329 pp. ISBN 9788072623242.
- TIETZ, Norbert. *Tietz Textbook of Clinical Chemistry and Molecular Diagnostics*. 4. edition. Elsevier Saunders, 2006. 2412 pp. ISBN 9780721601892.

References

- Laboratory manual of the FNOL Transfusion Department (https://www.fnol.cz/pdf/to/to-tabulka-odberovych-sys temu_2014.pdf)